

## Software Compatibility with UPS Via USB or Serial Cable (Peer-to-peer)

	3S, Ellipse ASR, Ellipse ECO, Ellipse MAX, Nova	3105, 5110, 5115, 5125, 5130, 9130, 9135, 9140, 9170+	Evolution, Evolution S, 5PX, EX, EXRT, MX	E Series NV & DX	BladeUPS
<b>Protection and supervision software</b>					
Winpower				x	
Intelligent Power Protector		x	x		
Intelligent Power® Manager (supervision only)	x	x	x	x*	x
LanSafe®		x			x
Personal Solution-Pac	x		x		
Integrated Power Manager	x		x		

\* DX only, fitted with SNMP card and using standard RFC1628 MIB

## Software and Connectivity Compatibility with Ethernet and Connectivity Card (Network)

When purchasing additional software, make sure that it is compatible with your UPS's connectivity card.

	USB Port	RS232 Port	RS485 Port	ConnectUPS-MS	ConnectUPS-BD	ConnectUPS-X	Network Management Card - Mini-Slot	619-00001-02 Web/SNMP Adaptor	619-00246-00 Web/SNMP Adaptor	Bestlink Web/SNMP Adaptor 116750225-001	Modbus/Jbus and Network Management Card—Mini-Slot	Power Xpert Gateway UPS Card	X-Slot® Modbus Card	AS/400 Status Card—Mini-Slot	X-Slot AS/400 Relay Card	X-Slot Industrial Relay Card	Environmental Monitoring Probe	Expansion Chassis
<b>Supervision software—monitors and manages UPSs and connected devices</b>																		
LanSafe	x	x		x	x	x					x	x						
Intelligent Power Protector	x	x		x	x	x	x				x	x						
Winpower	x	x						x	x									
Enterprise Power Manager				x	x*	x*	x				x	x*						
PowerVision®					x	x						x						
Intelligent Power Manager	x	x		x	x	x	x	x***	x***		x	x						
Power Xpert® Server—Professional				x	x	x	x				x	x						
Power Xpert Server—Enterprise				x	x	x	x				x	x						
Foreseer™				x	x	x	x				x	x						
<b>Protection software—graceful shutdown of OSs on servers and PCs</b>																		
LanSafe	x	x		x	x	x												
Intelligent Power Protector	x	x		x	x	x					x	x						
Winpower	x	x						x	x									
NetWatch				x	x	x	x				x	x						
Network Shutdown Module				x			x				x							
PowerVision Facilities Edition**					x	x						x						
<b>Connectivity compatibility</b>																		
3S	x																	
3105	x																	
Ellipse ASR	x	x																
Ellipse ECO	x																	
Nova AVR	x																	
E Series NV	x																	
5110	x																	
Ellipse Max	x	x																
5115	x	x																
5115 RM	x	x					x					x	x		x			
5125		x					x					x	x		x	x		x
Evolution®/Evolution S	x	x					x							x				
5130	x	x		x														
5PX	x	x		x			x				x				x			
E Series DX 1 Phase		x						x										
EX	x	x		x			x				x				x			
MX frame	x	x		x			x				x				x			
FERRUPS		x								x								
9130	x	x		x	x										x			
MX	x	x					x				x				x			
9135	x	x		x											x			
EX RT		x		x			x	x			x				x			
9140	x	x					x					x	x		x	x		x
9155		x					x					x	x		x	x		x
9170+		x		x	x									x				
E Series DX 3 Phase		x	x						x									
9355		x					x					x	x		x	x		x
BladeUPS		x					x					x	x		x	x		x
9315		x					x					x	x		x	x		x
9390		x					x					x	x		x	x		x
9390IT		x					x					x	x		x	x		x
9395		x					x					x	x		x	x		x
ConnectUPS-MS/X/BD, Network Management Card, Power Xpert Gateway 2000, Power Xpert UPS Card																		x

\*Limited capability with these cards

\*\*PowerVision Facilities Edition recommended for shutdown of paralleled UPS modules

\*\*\*Basic interface using RFC1628 MIB